

OVERSHOES & DISPENSER

30-551-5000/01

Easy-to-use overshoe dispenser, ideal to EPA or clean-room visitors
The dispenser is delivered without overshoes.
The overshoes are specifically designed for this dispenser.



Overshoe specifications

Material:	Fabric with a conductive ribbon
Weight:	40 g/m ²
Colour:	blue
Size:	Fits to all sizes between 35 & 48
Resistance to ground:	10e5 Ω
Usage precautions:	Do not wash, do not put in contact with detergents.
Packaging:	50 pairs/bag – 20 bags/box

Part numbers

Dispenser:	30-551-5000
Overshoes:	30-551-5001

How to fill in the dispenser

- 1- Open the box
- 2- Push the side rails up to the click
- 3- Bind the 10-packed overshoes to the rings at each angle (up to 5 packs)
- 4- Unclick the side rails by pushing them
- 5- Close the dispenser which is now ready to use

How to use the dispenser



- Put one foot after the other in the dispenser and push the pedal to the end.
- The overshoe is then automatically put around the shoe
- The conductive ribbon should be manually adjusted into the shoe.